

Masters & Working Directories

SpecsIntact draws on two types of folders for content -- Masters and Working Directories.

Masters contain the Master text specification Sections you will use to create Jobs or your own specialized local Masters.



Working Directories hold the Jobs and Local Masters you create. SpecsIntact allows you to access multiple Working Directories so that you don't have to store all your projects in the same location.

You can control which Jobs and Masters folders are displayed in the SI Explorer, and change the display at any time.

Masters & Working Directories

If you have no previous installation of SpecsIntact on your computer, you will be prompted to set up your Working Directories and connect your Masters when you open the software for the first time.

If previous version of the software exist on your system, the software will try to locate your Masters and Working Directories.



The Setup menu contains commands for accessing Masters and Working Directories that are available to your system.

At any time, you can add or remove Masters or Working Directory folders from the SI Explorer display by using the Setup menu.

Working Directories

From this dialog box, you can choose which working Directories you want visible in the SI Explorer, create new Working Directories, and establish the default location for new Jobs.

Any Working Directories listed in the text box that have checks beside them are connected and will have their contents displayed in the SI Explorer. Click to remove the check if you don't want to display the contents of that Working Directory.

The location of your current default Working Directory for all new Jobs is displayed here.

Working Directories

In the list below, enter the directory path(s) containing your projects. SPECSINTACT will search any active paths (any path with a check mark) for current Jobs and Masters.

The Default Directory is where new projects will be stored; this can be overridden as the project is created.

Working Directory Paths

<input checked="" type="checkbox"/> c:\sisgm1	<input type="button" value="Add to List..."/> <input type="button" value="Remove from List"/> <input type="button" value="Set as Default Directory"/>
<input checked="" type="checkbox"/> d:\si	
<input checked="" type="checkbox"/> c:\new si jobs	

Default directory for New Projects
d:\si

OK Cancel Help

Working Directories

Add to List allows you to browse for additional Working Directories or create a new one by entering it at the end of a path.

Remove from List allows you to remove the highlighted Working Directory from the list without removing it from your system.

Set as Default Directory allows you to designate the highlighted Working Directory as your default folder for new Jobs. You have the option of choosing a different folder when creating a new Job.

Working Directories

In the list below, enter the directory path(s) containing your projects. SPECSINTACT will search any active paths (any path with a check mark) for current Jobs and Masters.

The Default Directory is where new projects will be stored; this can be overridden as the project is created.

Working Directory Paths



<input checked="" type="checkbox"/> c:\sisgm1	<input type="button" value="Add to List..."/> <input type="button" value="Remove from List"/> <input type="button" value="Set as Default Directory"/>
<input checked="" type="checkbox"/> d:\si	
<input checked="" type="checkbox"/> c:\new si jobs	

Default directory for New Projects
d:\si

OK Cancel Help

Working Directories

All the Jobs contained in the Working Directories that you connected (checked) will be displayed in the SI Explorer.



Your default Working Directory will be displayed in the Path box of the New Job dialog box.

You can use the Working Directories button to connect additional locations for Jobs.

All the Working Directories that are connected (checked) will be displayed in the pull-down area, allowing you to choose the location for the Job you are creating.

Masters

Using this dialog box, you can choose which Masters you want displayed in the SI Explorer.

SpecsIntact searches your system and displays the name and location of all Masters it finds.



You can control which Masters are displayed in the SI Explorer by checking or un-checking them here.

Checked Masters are *connected*. Their contents will be displayed in the SI Explorer and available for setting up your Jobs.

Masters

Scan allows you to search for Masters on any drive or network available to your system.

Connect Masters

Master Name	Directory
<input type="checkbox"/> EFACHES	G:\SISGML\MASTERS
<input type="checkbox"/> EFANE	G:\SISGML\MASTERS
<input type="checkbox"/> EFANW	G:\SISGML\MASTERS
<input type="checkbox"/> EFAWEST	G:\SISGML\MASTERS
<input type="checkbox"/> LANTDIV	G:\SISGML\MASTERS
<input checked="" type="checkbox"/> LOCAL	C:\SISGML\MASTERS
<input checked="" type="checkbox"/> NASA	G:\SISGML\MASTERS
<input checked="" type="checkbox"/> NASAKSC	G:\SISGML\MASTERS
<input type="checkbox"/> OKINAWA	G:\SISGML\MASTERS
<input type="checkbox"/> SOUTHDIV	G:\SISGML\MASTERS
<input type="checkbox"/> SWDIV	G:\SISGML\MASTERS
<input checked="" type="checkbox"/> UFGS	G:\SISGML\MASTERS

All Masters that are connected (checked) are available in the pull-down list from which you choose your primary Master.

Primary Master: NASA
 LOCAL
 NASA
 NASAKSC
 UFGS

Search Time: 5 seconds Total Found: 12

OK Cancel Help

Masters

All the Masters that you connected (checked) will be displayed in the SI Explorer.

SpecsIntact

Available Projects: Masters

Contents of 'Masters':

Name	Master Title
LOCAL	New Local Master
NASA	
NASAKSC	
UFGS	

4 Masters

Create New Job

General Specifiers Options Comments

Job Name: Date Created:

Title:

Contract: Location:

Specifier: Source:

Path: C:\log\ Working Directory:

Primary Master Name: NASA

Submit Register Format

☐ Unified Submittal Description

Connect Masters

Your Primary Master will be displayed in the New Job dialog box.

All the Masters that are connected (checked) will be displayed in the pull-down area, giving you the option of selecting a different Primary Master for the Job.

Additional Masters can be connected using this button.

Cancel Help


SpecsIntact

Masters & Working Directories

The SI Explorer allows you to view the contents of all

Working Directories and Masters

that you connect using the Setup menu.



Each time you open SpecsIntact, it will locate the same connected Working Directories and Masters until you change them using the Setup menu commands.



To view another QuickTour, click the QT button.



